



## *BX- 12 Instructions*



*1. Remove hing tubes from gate and install in extension as shown. Tighten set screw at top and use 7/8" bolt at bottom.*



*2. Connect extension to gate frame as shown using 5" connecting bracket at top with 1" phillips head bolts and lock nuts. Connect bottom using short bracket and 1/4" x 1" hex bolt and lock nuts as shown.*

*Attach to surface according to gate mounting instructions.*

